

## PRINTED CIRCUIT BOARD REPAIR (Cont.)



## **Pure Copper Circuit Tape**

1/8" wide roll of self-adhesive pure copper tape for quick repairs or circuit modification. Adheres readily to PC boards and similar surfaces; solders readily. Flexible enough to be used around corners, between PC boards, between board and chassis, etc. Extremely low resistance. 1/8" Wide

Part No. 22-511 .0014" Thick 20 foot

0-10-10-10-10
CALENSALES
CARACARA A
and and and and a

## **Drill Bit Sets**

For drilling component lead wire holes in phenolic and glass epoxy PC boards. Made of high speed tool steel for long life.

Part No. 22-275	
	No. 66 Bit .0330" Dia. No. 60 Bit 0440" Dia. No. 1/16 Bit .0625" Dia.